

ANALYTICAL LABORATORIES, INC.

SAMPLE TYPE CODE

S - Routine Sample
 P - Repeat Sample (at original tap)
 E - Enforcement (chain of custody)
 U - Upstream Repeat
 D - Downstream Repeat
 X - Other Repeat
 W - Untreated
 V - Invalidated by Lab
 C - Construction / Special

**SAMPLING INSTRUCTIONS
 AND EXPLANATIONS ON
 THE BACK OF THIS FORM**

ID00020
 1804 N. 33rd Street
 Boise, Idaho 83703
 1-800-574-5773
 1-208-342-5515

Public Water Supply

Private Water Supply

Other _____

NAME OF WATER SYSTEM	COUNTY	PWS
----------------------	--------	-----

REPORT RESULTS TO:	DATE RECEIVED:
	TIME RECEIVED:

SEND ADDITIONAL COPIES TO:	DATE ANALYZED: (Set up)
	TIME ANALYZED: (Set up)

E-mail	IF RETEST, ORIGINAL SAMPLE DATE:			
Phone	Ext.	Fax	CHILLED 10° C	<input checked="" type="checkbox"/> YES <input type="checkbox"/> NO

COLLECTED BY:	TRANSPORTED BY:
---------------	-----------------

SAMP LE TYPE	COLLECTION DATE/TIME	Sampling Location	Cl res	TOTAL COLIFORMS SM 9223	E. COLI SM 9223	HPC SM 9215
		LAB #				
		LAB #				
		LAB #				
		LAB #				
		LAB #				
		LAB #				
		LAB #				
		LAB #				

REMARKS:	SET UP ANALYST:	READ OUT:
----------	-----------------	-----------

RECEIVED BY: (SIGNATURE) DATE AND TIME	RECEIVED BY: (PRINT NAME)
--	---------------------------

RELINQUISHED BY: (SIGNATURE) DATE AND TIME	RELINQUISHED BY: (PRINT NAME)
--	-------------------------------

RECEIVED AT LABORATORY BY: (SIGNATURE)	RECEIVED AT LABORATORY BY: (PRINT NAME)
--	---

INSTRUCTIONS AND EXPLANATIONS

SAMPLE COLLECTION:

1. Select a clean faucet. Avoid collecting from a swivel or hinged faucet as bacterial growth may occur in the cracks.
2. Remove all screens or strainers before taking the sample.
3. Allow water to run 3-5 minutes before taking the sample.
4. **Do not remove the cap from the bottle until just before taking the sample. There may be a white tablet or a small amount of moisture in the bottle. Do not remove the tablet from the bottle or rinse the bottle.** While you are filling the bottle, hold onto the cap so that neither the lip of the bottle or the inside surface of the cap touch anything, especially your fingers. **Fill the bottle to just above the 100 mL fill line leaving 1" of headspace** to allow for mixing the sample. Replace and tighten cap.
5. Coliform samples must reach the laboratory within 30 hours of taking sample.
6. Keep the sample cold but do not freeze.
7. Fill out label on bottle.

FILLING OUT FORM:

Person submitting water sample must fill in the un-shaded areas as completely as possible.

1. **Designate whether the Sample is from a Public Water System or a Private System.**
2. **Water System Name:** Name of public water system.
3. **County.**
4. **PWS ID No:** Number assigned by the Department of Environment Quality to Public Water Systems.
5. **Where the final report is to be sent.**
6. **Send Additional Copies to:** Designate where additional copies need to be sent.
7. **Date of Original Positive Sample:** Only fill this out if the sample is a repeat sample following a previous positive sample.
8. **Phone Number:** Record the phone number of the person responsible for the system or the designee.
9. **Fax Number:** Optional.
10. **E-mail:** Optional.
11. **Condition of transport:** Check appropriate box.
12. **Collector:** Full name of person collecting sample.
13. **Person transporting sample to laboratory:** Full name of person or entity transporting sample.
14. **Sample Type Code:** Select the sample type code that applies.
15. **Date Collected:** Include the day, month and year.
16. **Time Collected:** Use Military time or include a.m. or p.m.
17. **Sampling Location:** Indicate specifically where the sample was collected.
18. **Chlorine residual PPM:** If measured, record chlorine residual in mg/l, and whether free or total.

EXPLANATION OF TEST RESULTS:

1. **Total coliforms Absent:** The sample met the standards established by EPA and no total coliform bacteria were found in the sample.
2. **Total coliforms Present:** The sample contained coliform bacteria and may contain disease-causing organisms. Water should be sanitized before use.
3. **E. coli or Fecal coliforms Present:** The sample contained fecal material and is more likely to contain organisms, which cause disease. Water that contains fecal material should not be used for drinking, personal hygiene or in the preparation of food.

TESTING PRICES:

TOTAL COLIFORM PRESENCE / ABSENCE	: \$16.00
TOTAL COLIFORM ENUMERATION	: \$22.00
HETEROTROPHIC PLATE COUNT	: \$18.00
RUSH CHARGE	: \$5.00

FOR MORE INFORMATION SEE OUR WEBSITE AT WWW.ANALYTICALLABORATORIES.COM